TravelMate 240/250 series
User's guide

Copyright © 2003. Acer Incorporated.
All Rights Reserved.

TravelMate 240/250 series User's guide
Original Issue: June 2003

Changes may be made periodically to the information in this publication without obligation to notify any person of such revision or changes. Such changes will be incorporated in new editions of this manual or supplementary documents and publications. This company makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims the implied warranties of merchantability or fitness for a particular purpose.

Record the model number, serial number, purchase date, and place of purchase information in the space provided below. The serial number and model number are recorded on the label affixed to your computer. All correspondence concerning your unit should include the serial number, model number, and purchase information.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopy, recording, or otherwise, without the prior written permission of Acer Incorporated.

TravelMate 240/250 series Notebook computer

Model Number : ___________________________________

Serial Number: ____________________________________

Purchase Date: ____________________________________

Place of Purchase: ________________________________

Acer and the Acer logo are registered trademarks of Acer Incorporated. Other company's product names or trademarks are used herein for identification purposes only and belong to their respective companies.

First things first

We would like to thank you for making the TravelMate series of notebook computers your choice for your mobile computing needs. We hope you will be happy with your TravelMate as much as we enjoyed making it for you.

Your guides

To help you use your TravelMate, we have designed a set of guides:

First off, the **Just for Starters...** poster helps you get started with setting up your computer.

This **User's guide** introduces you to the many ways your computer can help you be more productive. This guide provides clear and concise information about the computer, so read it thoroughly.

If you ever need to print out a copy, this User's guide is also available in PDF (Portable Document Format). Follow these steps:

1 Click on **Start**, **Programs**, **TravelMate**.

2 Click on **TravelMate User's guide**.

Note: Viewing the file requires Adobe Acrobat Reader installed. If Adobe Acrobat Reader is not installed on your computer, clicking on TravelMate User's guide will run the Acrobat Reader setup program first. Follow the instructions on the screen to complete the installation. For instructions on how to use Adobe Acrobat Reader, access the **Help** menu.

Basic care and tips for using your computer

Turning your computer on and off

To turn on the computer, simply press and release the power switch below the LCD screen beside the Launch keys. See "Front view" on page 3 for the location of the power switch.

To turn the power off, do any of the following:

- Use the Windows shutdown command

  Click on **Start**, **Turn Off Computer**; then click on **Turn Off**.

- Use the power switch

  Note: You can also use the power switch to perform power management functions. See "Power management" on page 26.

- Use the customized functions for power management

  You can also shut down the computer by closing the display cover, or by pressing the sleep hot key (**Fn-F4**). See "Power management" on page 26.

  Note: If you cannot power off the computer normally, press and hold the power switch for more than four seconds to shut down the computer. If you turn off the computer and want to turn it on again, wait at least two seconds before powering up.

Taking care of your computer

Your computer will serve you well if you take care of it.

- Do not expose the computer to direct sunlight. Do not place it near sources of heat, such as a radiator.
- Do not expose the computer to temperatures below 0ºC (32ºF) or above 50ºC (122ºF).
- Do not subject the computer to magnetic fields.
- Do not expose the computer to rain or moisture.
- Do not spill water or any liquid on the computer.
- Do not subject the computer to heavy shock and vibration.
- Do not expose the computer to dust and dirt.

- Never place objects on top of the computer to avoid damaging the computer.
- Do not slam the computer display when you close it.
- Never place the computer on uneven surfaces.

Taking care of your AC adapter

Here are some ways to take care of your AC adapter:

- Do not connect the adapter to any other device.
- Do not step on the power cord or place heavy objects on top of it. Carefully route the power cord and any cables away from personal traffic.
- When unplugging the power cord, do not pull on the cord itself but pull on the plug.
- The total ampere ratings of the equipment plugged in should not exceed the ampere rating of the cord if you are using an extension cord. Also, the total current rating of all equipment plugged into a single wall outlet should not exceed the fuse rating.

Taking care of your battery pack

Here are some ways to take care of your battery pack:

- Use only batteries of the same kind as replacements. Turn the power off before removing or replacing batteries.
- Do not tamper with batteries. Keep them away from children.
- Dispose of used batteries according to local regulations. Recycle if at all possible.

Cleaning and servicing

When cleaning the computer, follow these steps:

1 Power off the computer and remove the battery pack.

2 Disconnect the AC adapter.

3 Use a soft cloth moistened with water. Do not use liquid or aerosol cleaners.

If any of the following occurs:

- The computer has been dropped or the body has been damaged.
- Liquid has been spilled into the product.

- The computer does not operate normally.

Please refer to "Troubleshooting my computer" on page 57.

First things first iii
    Your guides iii
    Basic care and tips for using your computer iv

1 Getting to know your TravelMate 1

A TravelMate tour 3
    Front view 3
    Left view 5
    Right view 6
    Rear view 7
    Bottom view 8
Features 9
Indicators 11
    Indicators in Cover 12
Using the keyboard 13
    Special keys 13
Touchpad 20
    Touchpad basics 20
Storage 22
    Hard disk 22
    Optical drive 22
    Floppy drive 24
Audio 25
Power management 26
Moving around with your TravelMate 27
    Disconnecting from the desktop 27
    Moving around 27
    Taking the computer home 28
    Traveling with the computer 30
    Traveling internationally with the computer 30
Securing your computer 32
    Using a computer security lock 32

2 Customizing my computer 35

Expanding through options 37
    Connectivity options 37
    Upgrade options 40
Using system utilities 43
    Notebook Manager 43
    Launch Manager 44
    BIOS Utility 45

3 Troubleshooting my computer 57
Frequently-asked questions 59
Requesting service 63
    International Traveler's Warranty (ITW) 63
    Before you call 63

Appendix A Specifications 65

Appendix B Notices 71

Index 81

1 Getting to know your TravelMate

Your TravelMate computer combines high-performance, versatility, power management features and multimedia capabilities with a unique style and ergonomic design. Work with unmatched productivity and reliability with your new power computing partner.

A TravelMate tour

After setting up your computer as illustrated in the **Just for Starters...** poster, let us show you around your new TravelMate computer.

Front view



#	Item	Description
1	Display screen	Also called LCD (liquid-crystal display), displays computer output.

#	Item	Description
2	Status indicators	LEDs (light-emitting diodes) that turn on and off to show the status of the computer, its functions and components.
3	Launch Keys	Buttons for launching frequently used programs. See“Launch Keys” on page 19 for more details.
4	Power switch	Turns on the computer power.
5	Palmrest	Comfortable support area for your hands when you use the computer.
6	Click buttons (left, center and right)	The left and right buttons function like the left and right mouse buttons; the center button serves as a 4-way scroll button.
7	Touchpad	Touch-sensitive pointing device which functions like a computer mouse.
8	Keyboard	Inputs data into your computer.
9	Ventilation Slot	Enables the computer to stay cool, even after prolonged use..

Left view



#	Item	Description
1	PC Card slot	Connects to two Type II 16-bit PC Card or 32-bit CardBus PC Card.
2	Eject button	Ejects the PC Card from the slot.
3	Optical drive	Internal optical drive; accepts CDs or DVDs depending on the optical drive type.
4	Infrared port	Interfaces with infrared devices (e.g., infrared printer, IR-aware computer).
5	LED indicator	Lights up when the optical drive is active.
6	Emergency eject button	Ejects the optical drive tray when the computer is turned off. See page 60 for more details.
7	Eject button	Ejects the optical drive tray from the drive.
8	Speaker	Delivers stereo audio output.

Right view



#	Item	Description
1	Speaker	Delivers stereo audio output.
2	Floppy activity indicator	LED (light-emitting diode) that turns on and off when the floppy is active.
3	Floppy drive	Internal diskette drive; accepts 3.5-inch diskettes.
4	Floppy disk eject button	Push this button to eject the floppy disk.
5	Security keylock	Connects to a Kensington-compatible computer security lock.

Rear view



#	Item	Description
1	Power jack	Connects to an AC adapter.
2	Parallel port	Connects to a parallel device (e.g., parallel printer).
3	External display port	Connects to a display device (e.g., external monitor, LCD projector) and displays up to 16M colors at 1024x768 resolution.
4	USB 2.0 ports (4)	Connect to Universal Serial Bus (USB) 2.0 devices (e.g., USB mouse, USB camera).
5	Network jack	Connects to an Ethernet 10/100-based network.
6	Modem jack	Connects to a phone line.
7	Speaker/Line-Out/ Headphone jack	Connects to audio line-out devices (e.g., speakers, headphones).
8	Line-in/Mic-in jack	Accepts audio line-in devices (e.g., audio CD player, stereo walkman).

Bottom view



#	Item	Description
1	Battery bay	Houses the computer's battery pack.
2	Battery release latch	Unlatches the battery to remove the battery pack.
3	Memory compartment	Houses the computer's main memory.

Features

Below is a brief summary of the computer's many features:

Performance

- Mobile Intel® Pentium® 4 processor with 512 KB L2 cache or Intel® Celeron® processor with 128 KB L2 cache
- CD, DVD, DVD/CD-RW combo drive or DVD rewritable
- Built-in floppy drive
- High-capacity Enhanced-IDE hard disk
- High-capacity battery pack
- Advanced Configuration Power Interface (ACPI) power management system

Display

- 14.1" or 15" Thin-Film Transistor (TFT) liquid crystal display (LCD) displaying 16M color at 1024x768 XGA (eXtended Graphics Array) resolution
- 3D capabilities
- Simultaneous LCD and CRT display support
- Supports other output display devices such as LCD projection panels for large-audience presentations
- "Automatic LCD dim" feature that automatically decides the best settings for your display and conserves power
- Dual display capability

Multimedia

- 16-bit high-fidelity AC'97 stereo audio with 3D sound and wavetable synthesizer
- Built-in dual speakers
- High-speed CD, DVD, DVD/CD-RW or DVD rewritable combo drive

Connectivity

- High-speed fax/data modem port
- Ethernet/Fast Ethernet port
- USB (Universal Serial Bus) 2.0 ports
- 802.11a+g/802.11b wireless LAN option
- Bluetooth option

Human-centric design and ergonomics

- All-in-one design (CD, DVD or combo drive, floppy drive, and hard disk)
- Sleek, smooth and stylish design
- Full-sized keyboard
- Ergonomically-centered touchpad pointing device

Expansion

- Two Type II CardBus PC Card slots
- Upgradeable memory

Indicators

The computer has six easy-to-read status icons below the display screen.



The Power and Sleep status icons are visible even when you close the display cover so you can see the status of the computer while the cover is closed.

Icon	Function	Description
💡	Power	Lights when the computer is on.
Zz	Sleep	Lights when the computer enters Standby mode and blinks when it enters into or resumes from hibernation mode.
◈	Media Activity	Lights when the floppy drive, hard disk or optical drive is active.
🔋	Battery Charge	Lights when the battery is being charged.
A	Caps Lock	Lights when Caps Lock is activated.

Icon	Function	Description
🔒	Num Lock	Lights when Num Lock is activated.

Indicators in Cover

When the cover of your computer is closed, 2 easy-to-read icons are shown, indicationg which state or feature is enabled or disabled.



Icon	Description
💡	Lights up when the computer is on.
Zz	Lights when the computer enters Standby mode and blinks when it enters into or resumes from hibernation mode.

Using the keyboard

The keyboard has full-sized keys and an embedded keypad, separate cursor keys, two Windows keys and twelve function keys.

Special keys

Lock keys

The keyboard has three lock keys which you can toggle on and off.



Lock key	Description
Caps Lock	When Caps Lock is on, all alphabetic characters typed are in uppercase.
Num Lock (Fn-F11)	When Num Lock is on, the embedded keypad is in numeric mode. The keys function as a calculator (complete with the arithmetic operators +, -, *, and /). Use this mode when you need to do a lot of numeric data entry. A better solution would be to connect an external keypad.
Scroll Lock (Fn-F12)	When Scroll Lock is on, the screen moves one line up or down when you press the up or down arrow keys respectively. Scroll Lock does not work with some applications.

Embedded numeric keypad

The embedded numeric keypad functions like a desktop numeric keypad. It is indicated by small characters located on the upper right corner of the keycaps. To simplify the keyboard legend, cursor-control key symbols are not printed on the keys.



Desired access	Num lock on	Num lock off
Number keys on embedded keypad	Type numbers in a normal manner.	
Cursor-control keys on embedded keypad	Hold Shift while using cursor-control keys.	Hold Fn while using cursor-control keys.
Main keyboard keys	Hold Fn while typing letters on embedded keypad.	Type the letters in a normal manner.

Note: If an external keyboard or keypad is connected to the computer, the Num Lock feature automatically shifts from the internal keyboard to the external keyboard or keypad.

Windows keys

The keyboard has two keys that perform Windows-specific functions.



Key	Description
Windows logo key ⊞	Start button. Combinations with this key perform shortcut functions. Below are a few examples: ⊞ + Tab (Activates next taskbar button) ⊞ + E (Explores My Computer) ⊞ + F (Finds Document) ⊞ + M (Minimizes All) Shift + ⊞ + M (Undoes Minimize All) ⊞ + R (Displays the Run... dialog box)
Application key ☰	Opens a context menu (same as a right-click).

Hot keys

The computer employs hot keys or key combinations to access most of the computer's controls like screen brightness, volume output and the BIOS Utility.

To activate hot keys, press and hold the **Fn** key before pressing the other key in the hot key combination.



Hot key	Icon	Function	Description
Fn-F1	?	Hot Key Help	Displays help on hot keys.
Fn-F2		Setup	Accesses the computer's configuration utility.
Fn-F3	✓	Power Management Scheme Toggle	Switches the power management scheme used by the computer (function available if supported by operating system).
Fn-F4	Zz	Sleep	Puts the computer in Sleep mode.

Hot key	Icon	Function	Description
Fn-F5	▭|■	Display Toggle	Switches display output between the display screen, external monitor (if connected) and both the display screen and external monitor.
Fn-F6	☼▸■	Screen Blank	Turns the display screen backlight off to save power. Press any key to return.
Fn-F7	▭	Touchpad Toggle	Turns the internal touchpad on and off.
Fn-F8	🔇/🔊	Speaker Toggle	Turns the speakers on and off.
Fn-↑	🔊	Volume up	Increases the sound volume.
Fn-↓	🔉	Volume down	Decreases the sound volume.
Fn-→	☼	Brightness up	Increases the screen brightness.
Fn-←	☀	Brightness down	Decreases the screen brightness.
Fn-PgUp	Pg Up Home	Home	Functions as the “Home” key.
Fn-PgDn	Pg Dn End	End	Functions as the “End” key.
Alt Gr-Euro	€	Euro	Types the Euro symbol.

The Euro symbol

If your keyboard layout is set to United States-International or United Kingdom or if you have a keyboard with a European layout, you can type the Euro symbol on your keyboard.

Note for US keyboard users: The keyboard layout is set when you first set up Windows. For the Euro symbol to work, the keyboard layout has to be set to United States-International.

To verify the keyboard type:

1. Click on **Start**, **Control Panel**.
2. Double-click on **Regional and Language Options**.
3. Click on the **Language** tab and click on **Details**.
4. Verify that the keyboard layout used for "En English (United States)" is set to United States-International.

   If not, select and click on **ADD**; then select **United States-International** and click on **OK**.
5. Click on **OK**.

To type the Euro symbol:

1. Locate the Euro symbol on your keyboard.
2. Open a text editor or word processor.
3. Hold **Alt Gr** and press the Euro symbol.

Some fonts and software do not support the Euro symbol. Please refer to http://www.microsoft.com/typography/faq/faq12.htm for more information.

Launch Keys

Located at the top of the keyboard are six buttons. These buttons are called launch keys. They are designated as Wireless, Bluetooth button, Web browser button, mail button, P1 and P2. The Wireless and Bluetooth buttons cannot be set by the user. To set the other four launch keys, run the Acer Launch Manager.



No.	Description	Default application
1	Mail	Email application
2	Web browser	Internet browser application
3	P1	User-programmable
4	P2	User-programmable
5	Bluetooth(optional)	Starts Bluetooth functionality and Indicates that Bluetooth is enabled.
6	Wireless(optional)	Opens wireless connectivity and Indicates status of wireless communication.

Caution: It's important that Bluetooth and Wireless LAN are turned off before boarding an airplane.

Touchpad

The built-in touchpad is a PS/2-compatible pointing device that senses movement on its surface. This means the cursor responds as you move your finger on the surface of the touchpad. The central location on the palmrest provides optimum comfort and support.

Note: When using an external USB or serial mouse, you can press **Fn-F7** to disable the touchpad.

Touchpad basics

The following items teach you how to use the touchpad:



- Move your finger across the touchpad to move the cursor.
- Press the left (#1) and right (#3) buttons located on the edge of the touchpad to do selection and execution functions. These two

buttons are similar to the left and right buttons on a mouse. Tapping on the touchpad produces similar results.

- Use the 4-way scroll (#2) button to scroll up or down and move left or right a page. This button mimics your cursor pressing on the right scroll bar of Windows applications.

Function	Left button	Right button	Center buttons	Tap
Execute	Click twice quickly			Tap twice (at the same speed as double-clicking a mouse button)
Select	Click once			Tap once
Drag	Click and hold, then use finger to drag the cursor on the touchpad			Tap twice (at the same speed as double-clicking a mouse button) then hold finger to the touchpad on the second tap and drag the cursor
Access context menu		Click once		
Scroll			Click and hold the up/ down/ left/ right	

Note: Keep your fingers dry and clean when using the touchpad. Also keep the touchpad dry and clean. The touchpad is sensitive to finger movements. Hence, the lighter the touch, the better the response. Tapping harder will not increase the touchpad's responsiveness.

Storage

This computer supplies you with the following media storage:

- High-capacity Enhanced-IDE hard disk
- Optical (CD, DVD, DVD/CD-RW combo, or DVD rewritable) drive
- Floppy drive

Hard disk

The high-capacity hard disk is the answer to your storage needs. This is where your data files and applications are stored.

Optical drive

Your computer comes equipped with an optical drive which may be one of the following:

- CD-ROM drive
- DVD-ROM drive
- DVD/CD-RW combo drive
- DVD rewritable

Ejecting the CD or DVD tray

To eject the CD or DVD tray when the computer is turned on, press the drive eject button; then pull out the tray.



When the power is off, you can eject the drive tray using the emergency eject hole. See page 60.

Playing DVD movies

When the DVD drive module is installed in the optical drive bay, you can play DVD movies on your computer.

1 Eject the DVD tray and insert a DVD movie disc; then close the DVD tray.

Important! When you launch the DVD player for the first time, the program asks you to input the region code. DVD discs are divided into 6 regions. Once your DVD drive is set to a region code, it will play DVD discs of that region only. You can set the region code a maximum of five times (including the first time), after which the last region code set will remain permanent. Recovering your hard disk does not reset the number of times the region code has been set. Refer to the table later in this section for DVD movie region code information.

2 The DVD movie will automatically play after a few seconds.

Region Code	Country or Region
1	U.S.A., Canada
2	Europe, Middle East, South Africa,Japan
3	Southeast Asia, Taiwan, Korea (South)
4	Latin America, Australia, New Zealand
5	Former U.S.S.R., parts of Africa, India
6	People's Republic of China

Note: To change the region code, insert a DVD movie of a different region into the DVD drive.

Floppy drive

The internal floppy drive accepts standard 3.5-inch, 1.44 MB diskettes.

Ejecting a diskette

Eject a diskette by pressing the floppy disk eject button (1) and pull out the diskette (2) to remove it.



Audio

The computer comes with 16-bit high-fidelity AC'97 stereo audio. The built-in dual stereo speakers are easy to access.



There are audio ports on the rear panel of the computer. See "Rear view" on page 7 for more information on external audio devices.

Power management

This computer has a built-in power management unit that monitors system activity. System activity refers to any activity involving one or more of the following devices: keyboard, mouse, floppy drive, hard disk, peripherals connected to the serial and parallel ports, and video memory. If no activity is detected for a period of time (called an inactivity timeout), the computer stops some or all of these devices in order to conserve energy.

This computer employs a power management scheme that supports ACPI (Advanced Configuration and Power Interface), which allows for maximum power conservation and maximum performance at the same time. Windows handles all power-saving chores for your computer.

Moving around with your TravelMate

This section gives you tips and hints on things to consider when moving around or traveling with your computer.

Disconnecting from the desktop

Follow these steps to disconnect your computer from external accessories:

1. Save your work in progress.
2. Remove any media, diskette or compact disc, from the drive(s).
3. Shut down the operating system.
4. Turn off the computer.
5. Close the display cover.
6. Disconnect the cord from the AC adapter.
7. Disconnect the keyboard, pointing device, printer, external monitor, and other external devices.
8. Disconnect the Kensington lock if you are using one to secure the computer.

Moving around

"when you are just moving within short distances, for example, from your office desk to a meeting room"

Preparing the computer

Before moving the computer, close and latch the display cover to place it in Sleep mode. You can now safely take the computer anywhere you go within the building. To bring the computer out of Sleep mode, open the display.

If you are taking the computer to a client's office or a different building, you may choose to shut down the computer:

1. Click on **Start**, **Turn Off Computer**.
2. Click on **Turn Off**.

- or -

you can put the computer in Sleep mode by pressing **Fn-F4**. Then close and latch the display.

When you are ready to use the computer again, unlatch and open the display, and press and release the power switch. If the power indicator is off, the computer has entered Hibernation mode and turned off. Press and release the power switch to turn the computer back on. Note that the computer may enter Hibernation mode after a period of time it is in Sleep mode. Turn the power on to wake up the computer from Hibernation mode.

What to bring to short meetings

A fully charged battery runs the computer for about 3.5 hours under most circumstances. If your meeting is shorter than that, you probably do not need to bring anything with you other than the computer.

What to bring to long meetings

If your meeting will last longer than 3.5 hours or if your battery is not fully charged, you may want to bring the AC adapter with you to plug in your computer in the meeting room.

If the meeting room does not have an electrical outlet, reduce the drain on the battery by putting the computer in Sleep mode. Press **Fn-F4** or close the display cover whenever you are not actively using the computer. Then tap any key or open the display to resume.

Taking the computer home

"when you are moving from your office to your home or vice versa"

Preparing the computer

After disconnecting the computer from your desktop, follow these steps to prepare the computer for the trip home:

- Check if you have removed all media, diskettes and compact discs, from the drive(s). Failure to remove the media can damage the drive head.
- Pack the computer in a protective case that can prevent the computer from sliding around and cushion it if it should fall.

Caution: Avoid packing items next to the top cover of the computer. Pressure against the top cover can damage the screen

What to bring with you

Unless you already have some items at home, bring the following items with you:

- AC adapter and power cord
- The printed user's manual

Special considerations

Follow these guidelines to protect your computer while traveling to and from work:

- Minimize the effect of temperature changes by keeping the computer with you.
- If you need to stop for an extended period of time and cannot bring the computer with you, leave the computer in the trunk of the car to avoid exposing the computer to excessive heat.
- Changes in temperature and humidity can cause condensation. Allow the computer to return to room temperature, and inspect the screen for condensation before turning on the computer. If the temperature change is greater than 18°F (10°C), allow the computer to come to room temperature slowly. If possible, leave the computer for 30 minutes in an environment with a temperature between outside and room temperature.

Setting up a home office

If you frequently work on your computer at home, you may want to purchase a second AC adapter for use at home. With a second AC adapter, you can avoid transporting the extra weight to and from home.

If you use your computer at home for significant periods of time, you might also want to add an external keyboard, monitor, or mouse.

Traveling with the computer

“when you are moving within a larger distance, for instance, from your office building to a client’s office building or traveling locally”

Preparing the computer

Prepare the computer as if you were taking it home. Make sure that the battery in the computer is charged. Airport security may require you to turn on your computer when bringing it into the gate area.

What to bring with you

Bring the following items with you:

- AC adapter
- Spare, fully-charged battery pack(s)
- Additional printer driver files if you plan to use another printer

Special considerations

In addition to the guidelines for taking the computer home, follow these guidelines to protect your computer while traveling:

- Always take the computer as carry-on luggage.
- If possible, have the computer inspected by hand. Airport security X-ray machines are safe, but do not put the computer through a metal detector.
- Avoid exposing floppy disks to hand-held metal detectors.

Traveling internationally with the computer

“when you are moving from country to country”

Preparing the computer

Prepare the computer as you would normally prepare it for traveling.

What to bring with you

Bring the following items with you:

- AC adapter

- Power cords that are appropriate for the country to which you are traveling
- Spare, fully-charged battery packs
- Additional printer driver files if you plan to use another printer
- Proof of purchase, in case you need to show it to customs officials
- International Traveler's Warranty passport

Special considerations

Follow the same special considerations as when traveling with the computer. In addition, these tips are useful when traveling internationally:

- When traveling in another country, check that the local AC voltage and the AC adapter power cord specifications are compatible. If not, purchase a power cord that is compatible with the local AC voltage. Do not use converter kits sold for appliances to power the computer.
- If you are using the modem, check if the modem and connector is compatible with the telecommunications system of the country you are traveling in.

Securing your computer

Your computer is a valuable investment that you need to take care of. Learn how to protect and take care of your computer.

Security features include hardware and software locks — a security notch and passwords.

Using a computer security lock

A security keylock notch located on the right panel of the computer lets you connect a Kensington-compatible computer security lock.



Wrap a computer security lock cable around an immovable object such as a table or locked drawer handle. Insert the lock into the notch and turn the key to secure the lock. Some keyless models are also available.

Setting a password

Follow these steps:

1 Use the cursor up/down keys to highlight a password parameter and press the Enter key. The password box appears.



```
                 Set Password

   Enter New Password    [          ]
 Confirm New Password    [          ]
```

2. Type a password. The password may consist of up to eight characters (A-Z, a-z, 0-9).
3. Press Enter. Retype the password to verify your first entry and press Enter.
4. After setting the password, the computer automatically sets the chosen password parameter to Present.

Removing a password

Should you want to remove a password, do the following:

1. Use the cursor up/down keys to highlight a password parameter and press the Enter key. The password box appears.
2. Enter the current password and press Enter.
3. Press Enter twice without entering anything in the new and confirm password fields to remove the existing password.



```
                 Set Password

Enter Current Password    [         ]
    Enter New Password    [         ]
  Confirm New Password    [         ]
```

Note: When you want to remove the Hard Disk (or 2nd Hard Disk) password, you are prompted for the current Hard Disk password before it is removed.

Changing a password

Should you want to change a password, do the following:

1. Remove the current password.
2. Set a new password.

Setting passwords

You can set passwords using:

- Notebook Manager
- BIOS Utility

2 Customizing my computer

After learning the basics of your TravelMate computer, let's get acquainted with the advanced features of your computer. In this chapter, you will learn how to add options, upgrade components for better performance, and customize your computer.

Expanding through options

Your TravelMate offers you a complete mobile computing experience.

Connectivity options

Ports allow you to connect peripheral devices to your computer as you would with a desktop PC.

Modem

Your computer has a built-in V.90/V.92 56Kbps AC’97 Link modem.

Warning! This modem port is not compatible with digital phone lines. Plugging this modem into a digital phone line will damage the modem.

To use the modem, connect a phone cable from the modem jack to a phone line jack.



Start your communications software program. See your communications manual for instructions.

Network

Your computer has built-in Ethernet/Fast Ethernet capabilities. To use the network feature, connect an Ethernet cable from the network jack to an network jack or hub. Consult your network administrator for details.



Universal Serial Bus

The Universal Serial Bus (USB) 2.0 port is a high-speed serial bus which allows you to connect and daisy-chain USB peripherals without taking up precious system resources. Your computer has four ports available.



PC Card slot

There are two Type II CardBus PC Card slots found on the left side of the computer. This slot accepts credit-card-sized cards that enhance the usability and expandability of the computer. These cards should have a PC Card logo on them.

PC Cards (formerly PCMCIA) are add-on cards for portable computers, giving you expansion possibilities long afforded by desktop PCs. CardBus improves on the 16-bit PC card technology by expanding the bandwidth to 32 bits.

Note: Refer to your card's manual for details on how to install and use the card and its functions.

Inserting a PC Card

Insert the card into the lower slot and make the proper connections (e.g., network cable), if necessary. See your card manual for details.



Ejecting a PC Card

Before ejecting a PC Card:

1 Exit the application using the card.

2 Left-click on the Safely Remove Hardware icon on the taskbar and click on the PC Card item. Click **OK** to confirm.

3 Press the slot eject button (1) to pop out the eject button; then press it again (1) to eject the card (2).



Upgrade options

Your computer delivers superior power and performance. However, some users and the applications they use may demand more. This computer allows you to upgrade key components when you need increased performance.

Note: Contact your authorized dealer if you decide to perform a key component upgrade.

Memory upgrade

Memory is expandable to 2 GB, employing DDR266/333 256MB/512MB/ 1GB SDRAM modules. Two DDR DIMM slots. The computer supports shadow RAM.

There are two memory slots on your computer, one of which is occupied by standard memory. You can upgrade memory by installing a memory module into the available slot, or replacing the standard memory with a higher-capacity memory module.

Installing memory

Follow these steps to install memory:

1. Turn off the computer, unplug the AC adapter (if connected) and remove the battery pack. Then turn the computer over to access its base.
2. Remove the screw from the memory cover (a); then lift up and remove the memory cover (b).



3 Insert the memory module diagonally into the slot (1), then gently press it down until it clicks into place (2).



4 Replace the memory cover and secure it with the screw.

The computer automatically detects and reconfigures the total memory size.

Using system utilities

Notebook Manager

The computer has a built-in system setup program called Notebook Manager. The Windows-based Notebook Manager allows you to set passwords, the startup sequence of the drives, and power management settings. It also shows current hardware configurations.

To start the Notebook Manager, press Fn-F2 or follow these steps:

1 Click on **Start**, **Programs**, then **Notebook Manager**.

2 Select the **Notebook Manager** application to run the program.

Click on **Help** for more information.


Notebook Manager
System Information
Settings
Help
Exit
System Information
Boot Options
Password
Display Device
Smart Card
acer
Notebook Manager
Volume Control
Power Scheme
Launch Manager
Invilink
Exit

Display system hardware information

Launch Manager

There are six Launch Keys located above the keyboard. The Wireless and Bluetooth buttons are not programmable. Launch Manager only allows you to set the other four Launch Keys. See “Launch Keys” on page 19 for more information.



Launch Manager

Wireless Device Boot status: Always On

Bluetooth Device Boot status: Always Off

E-Mail: "C:\Program Files\Outlook Express\msimn.ex

WWW: "C:\Program Files\Internet Explorer\iexplore.e

Launch Manager: "C:\Progra~1\Launch Manager\fn.exe"

Launch Manager: "C:\Progra~1\Launch Manager\fn.exe"

You can access the Launch Manager by clicking on **Start**, **Programs**, and then **Launch Manager** to start the application.

BIOS Utility

The BIOS Utility is a hardware configuration program built into your computer's BIOS (basic input/ouput system).

Your computer is already properly configured and optimized, and you do not need to run this utility. However, if you encounter configuration problems, you may need to run it.

To activate the BIOS Utility, press **F2** during the POST (power-on self-test) while the TravelMate logo is being displayed.



```
                    PhoenixBIOS Setup Utility
 Information     Main     Advanced     Security     Boot     Exit

 CPU Type              Intel (R)Celeron(R) CPU  2.4 GHz
 System Memory:        640 KB
 Extended Memory:      121344 KB
 HDD1 Serial Number    XXXXXX
 System BIOS Version   VX.XX(XXXXXXX)
 VGA BIOS Version      XXXX
 KBC Version           02.29.25
 Serial Number         XXXXXXXXXXXXXXXXX
 Asset Tag Number
 Product Name          TravelMate
 Manufacture Name      Acer
 UUID Number           00000000-0000-0000-0000-000000000000

 F1  Help  ↑↓ Select Item   -/+ Change Values       F9  Setup Defaults
 Esc Exit  ↔ Select Menu    Enter Select > Sub-Menu F10 Save and Exit
```

Navigating the BIOS Utility

These are the menu options: Information, Main, Advanced, Security, Boot and Exit.

To enter a menu, highlight the item using the ←→ keys.

Within a menu, navigate through the BIOS Utility by following these instructions:

- Press the cursor up/down keys (↑↓) to select item.
- Press the -/+ to change the value of a parameter.
- Press **Enter** to go to sub-menu.
- Press **Esc** while you are in any of the menu options to return to the main menu

Note: You can change the value of a parameter if it is enclosed in square brackets. Navigation keys for a particular menu are shown on the bottom of the screen.

Information

The Information screen displays a summary of your computer hardware information.



```
                    PhoenixBIOS Setup Utility
Information     Main     Advanced     Security     Boot     Exit

CPU Type               Intel (R)Celeron(R) CPU  2.4 GHz
System Memory:         640 KB
Extended Memory:       121344 KB
HDD1 Serial Number     XXXXXX
System BIOS Version    VX.XX(XXXXXXX)
VGA BIOS Version       XXXX
KBC Version            02.29.25
Serial Number          XXXXXXXXXXXXXXXXX
Asset Tag Number
Product Name           TravelMate
Manufacture Name       Acer
UUID Number            00000000-0000-0000-0000-000000000000

F1  Help ↑↓ Select Item   -/+ Change Values        F9  Setup Defaults
Esc Exit ←→ Select Menu   Enter Select > Sub-Menu  F10 Save and Exit
```

Note: The screen above is for reference only. Actual values may differ.

The table below describes the parameters in this screen.

Parameter	Description
CPU Type	Describes the type of CPU installed in the system.
System Memory (KB)	Shows the system memory size.
Extended Memory (MB)	Shows the extended memory size.

Parameter	**Description**
HDD1 Serial Number	Shows the primary master hard disk drive serial number.
System BIOS Version	Shows the system BIOS version.
VGA BIOS Version	Shows the video graphics accelerator BIOS version.
KBC Version	Shows the current keyboard controller (KBC) version
Serial Number	Shows the system serial number.
Asset Tag Number	Shows the asset tag number.
Product Name	Shows the official name of the product.
Manufacturer Name	Shows the name of the manufacturer.
UUID	Shows the universally unique identifier number.

Main

The Main menu screen allows you to set basic settings about your computer such as date and time and boot settings.


PhoenixBIOS Setup Utility
Information
Main
Advanced
Security
Boot
Exit
Item Specific Help
F1 Help
↑↓ Select Item
-/+ Change Values
F9 Setup Defaults
Esc Exit
↔ Select Menu
Enter Select > Sub-Menu
F10 Save and Exit

```
System Time:                    [10:10:35]
System Date:                    [10/26/2002]

Boot Display                    [Auto]

QuickBoot Mode:                 [Enabled]
Boot-time Diagnostic Screen:    [Disabled]

Boot on LAN                     [Disabled]
Hotkey Beep                     [Enabled]

Auto Dim                        [Enabled]
F12 Multi-Boot                  [Enabled]
```

<Tab>, <Shift-Tab>,or <Enter> selects field.

The table below describes the parameters in the screen.

Parameter	Description
System Time	Sets the system time. Format: HH:MM:SS (hour:minute:second)
System Date	Sets the system date. Format: MMM DD YYYY (month day year)
Boot Display	Sets the display device when the computer starts up. Options: Both or **Auto**
QuickBoot Mode	Quick Boot allows your computer to skip certain tests at start-up to speed-up the boot process. Options: **Enabled** or Disabled
Boot-time Diagnostic Screen	Shows the logo during boot up. Options: Enabled or **Disabled**
Boot on LAN	When enabled, allows your computer to boot up via the network Options: Enabled or **Disabled**
Hotkey Beep	Enables or disables a beep when a hotkey is pressed. Options: **Enabled** or Disabled
Auto Dim	When enabled, the system will automatically dim the LCD screen when system is running on battery power. Options: **Enabled** or Disabled
F12 Multi-Boot	When enabled, the “Fn-F12 for multi-boot” message will be displayed during POST. Options: **Enabled** or Disabled

Advanced

The Advanced screen contains parameters values that define how your computer behaves on startup.



```
                     PhoenixBIOS Setup Utility
 Information    Main     Advanced     Security     Boot     Exit

 Legacy Diskette A:          [1.44/1.25 MB 3½”]   Item Specific Help

 > Primary Master                [20004MB]
 > Secondary Master              [CD-ROM]

 > I/O Device Configuration
 > PCI IRQ Routing

   USB BIOS Legacy Support       [Enabled]

 F1  Help  ↑↓ Select Item   -/+ Change Values        F9  Setup Defaults
 Esc Exit  ←→ Select Menu   Enter Select > Sub-Menu  F10 Save and Exit
```

The table below describes the parameters in this screen. Settings in boldface are the default and suggested parameter settings.

Parameter	Description
Legacy Diskette A:	Shows the floppy drive information.
Primary Master	Shows the hard disk information. Press **Enter** to access the sub-menu.
Secondary Master	Shows the optical drive information. Press **Enter** to access the sub-menu.
I/O Device Configuration	Press **Enter** to access and set the I/O Device Configuration sub-menu.
PCI IRQ Routing	Press **Enter** to access and set the PCI IRQ Routing sub-menu.
USB BIOS Legacy Support	Enables or disables the USB BIOS Legacy Support. Options: **Enabled** or Disabled

Primary Master

The Primary Master sub-menu contains parameters related to the hard disk installed in your computer.



```
                    PhoenixBIOS Setup Utility
                 Advanced
        Primary Master  [20004MB]               Item Specific Help

 Type:                      [Auto]
                            LBA Format
 Total Sectors:             39070080
 Maximum Capacity:          20004MB

 Multi-Sector Transfers:    [16 Sectors]
 LBA Mode Control:          [Enable]
 32 Bit I/O:                [Disabled]
 Transfer Mode:             [Fast PIO 4]
 Ultra DMA Mode:            [Disabled]

F1  Help  ↑↓ Select Item   -/+ Change Values        F9  Setup Defaults
Esc Exit  ↔ Select Menu    Enter Select > Sub-Menu  F10 Save and Exit
```

Caution: The parameters in this screen are for advanced uses only. Typically, you do not need to change the values in this screen. The default setting of **Auto** optimizes all the settings in your hard disk drive.

Secondary Master

The Secondary Master sub-menu contains parameters related to the optical drive installed in your computer.



```
                    PhoenixBIOS Setup Utility
                         Advanced
        Secondary Master  [CD-ROM]              Item Specific Help

 Type:                      [Auto]

 Multi-Sector Transfers:    [Disabled]
 LBA Mode Control:          [Disabled]
 32 Bit I/O:                [Disabled]
 Transfer Mode:             [Standard]
 Ultra DMA Mode:            [Disabled]

F1  Help  ↑↓ Select Item   -/+ Change Values        F9  Setup Defaults
Esc Exit  ↔ Select Menu    Enter Select > Sub-Menu  F10 Save and Exit
```

Caution: The parameters in this screen are for advanced uses only. Typically, you do not need to change the values in this screen. The default setting of **Auto** optimizes all the settings in your hard disk drive.

I/O Device Configuration

The I/O Device Configuration sub-menu contains parameters that are related to your computer hardware.



```
                    PhoenixBIOS Setup Utility
                  Advanced
       I/O Device Configuration                  Item Specific Help

  Parallel port:            [Enable]
    Mode:                   [Bi-directional]
    Base I/O address:       [378]
    Interrupt:              [IRQ 7]

F1  Help ↑↓ Select Item   -/+ Change Values      F9  Setup Defaults
Esc Exit ↔ Select Menu    Enter Select > Sub-Menu F10 Save and Exit
```

.

Parameter	Description
Parallel Port	Enables or disables the parallel port. Options: **Enabled** or Disabled
Mode	Sets the operation mode of the parallel port. Options: Output only, **Bi-direction**, EPP, or ECP
Base I/O Address	Sets the I/O address of the parallel port. Options: 3BC, **378h**, or 278h
Interrupt	Sets the interrupt request of the parallel port. Options: IRQ 5 or **IRQ 7**

PCI IRQ Routing

The PCI IRQ Routing sub-menu allows you to set the IRQs for PCI devices.



```
                      PhoenixBIOS Setup Utility
                      Advanced
             PCI IRQ Routing                     Item Specific Help

 PCI IRQ A#:[11]
 PCI IRQ B#:[10]
 PCI IRQ C#:[11]
 PCI IRQ D#:[10]
 PCI IRQ E#:[11]
 PCI IRQ F#:[10]
 PCI IRQ G#:[11]
 PCI IRQ H#:[10]

F1  Help ↑↓ Select Item   -/+ Change Values       F9  Setup Defaults
Esc Exit ↔ Select Menu   Enter Select > Sub-Menu F10 Save and Exit
```

Caution: The parameters in this screen are for advanced users only. Typically, you do not need to change the values in this screen because these values are already optimized.

Security

The Security screen contains parameters that help safeguard and protect your computer from unauthorized use.



```
                     PhoenixBIOS Setup Utility
 Information     Main     Advanced     Security     Boot     Exit
 Set Supervisor Password           [Enter]      Item Specific Help
 Set User Password                 [Enter]

 Password on boot:                 [Enable]

 Set Primary Hard Disk Password    [Enter]

F1  Help  ↑↓ Select Item   -/+ Change Values       F9  Setup Defaults
Esc Exit  ↔ Select Menu    Enter Select > Sub-Menu F10 Save and Exit
```

The table below describes the parameters in this screen. Settings in boldface are the default and suggested parameter settings.

Parameter	Description
Set Supervisor Password	When set, this password protects the BIOS Utility from unauthorized entry. Press **Enter** to set this password.
Set User Password	When set, this password protects the computer from unauthorized entry during boot-up or resume from Hibernation mode. Press **Enter** to set this password.
Password on Boot	When enabled, a password is requested when the system boots up. Options: **Enabled** or Disabled
Set Primary Hard Disk Password	When set, this password prevents the primary hard disk from unauthorized access. It consists of 8 alphanumeric characters. Press **Enter** to set this password.

Boot

The Boot menu contains parameter values that determine in what order the bootable devices in your computer start-up.



```
                    PhoenixBIOS Setup Utility
 Information     Main     Advanced     Security     Boot     Exit

  +Removable Devices                              Item Specific Help
  +Hard Drive
   CD-ROM Drive

 F1  Help  ↑↓ Select Item   -/+ Change Values       F9  Setup Defaults
 Esc Exit  ←→ Select Menu   Enter Select > Sub-Menu F10 Save and Exit
```

Setting the Boot drive sequence

Use the cursor up/down keys to select a boot device, then press ↑ or ↓ to change its order. Items with a "+" sign can be further expanded.

Exit

This menu contains the exit options.



```
                  PhoenixBIOS Setup Utility
 Information    Main    Advanced    Security    Boot     Exit

 Exit Saving Changes                           Item Specific Help
 Exit Discarding Changes
 Load Setup Defaults
 Discard Changes
 Save Changes

 F1  Help  ↑↓ Select Item   -/+ Change Values      F9  Setup Defaults
 Esc Exit  ↔ Select Menu    Enter Execute Command  F10 Save and Exit
```

.

Parameter	Description
Exit Saving Changes	Saves your changes and exits the BIOS Utility.
Exit Discarding Changes	Discards your changes and exits the BIOS Utility.
Load Setup Defaults	Loads default settings for all setup parameters.
Discard Changes	Discards your changes.
Save Changes	Saves your changes.

3 Troubleshooting my computer

This chapter instructs you on how to deal with common system problems. Read it before calling a technician if a problem occurs. Solutions to more serious problems require opening up the computer. Do not attempt to open the computer by yourself. Contact your dealer or an authorized service center for assistance.

Frequently-asked questions

The following is a list of possible situations that may arise during the use of your computer. Easy answers and solutions are provided for each one.

I pressed the power switch and opened the display, but the computer does not start or boot-up.

Look at the Power indicator:

- If it is not lit, no power is being applied to the computer. Check the following:
    - If you are running on battery power, it may be low and unable to power the computer. Connect the AC adapter to recharge the battery pack.
    - Make sure that the AC adapter is plugged in properly to the computer and to the power outlet.
- If it is lit, check the following:
    - If the Sleep indicator is lit, the computer is in Sleep mode. Press any key or tap on the touchpad to resume.
    - Is a non-bootable (non-system) diskette in the floppy drive? Remove or replace it with a system diskette and press **Ctrl-Alt-Del** to restart the system.
- The operating system files may be damaged or missing. Insert the startup disk you created during Windows setup into the floppy drive and press **Ctrl-Alt-Del** to restart the system. This will diagnose your system and make necessary fixes.

Nothing appears on the screen.

The computer's power management system automatically blanks the screen to save power. Press any key to turn the display back on.

If pressing a key does not turn the display back on, two things might be the cause:

- The brightness level might be too low. Press **Fn-→** to increase the brightness level.
- The display device might be set to an external monitor. Press the display toggle hot key **Fn-F5** to toggle the display back to the computer.

Image is not full-screen.

Make sure that the resolution is set to 1024x768. This is the native resolution of your computer display. Right-click on your Windows desktop and select Properties to bring up the **Display Properties** dialog box. Then click on the Settings tab to make sure that the resolution is set to the appropriate resolution. Resolutions lower than the specified resolution are not full-screen on the computer or on an external monitor.

No audio is heard from the computer.

Check the following:

- The volume may be muted. In Windows, look at the volume control (speaker) icon on the taskbar. If it is crossed-out, click on the icon and deselect the Mute option.
- The speakers may be turned off. Press **Fn-F8** to turn the speakers on (this hot key also turns the speakers off).
- The volume level may be too low. In Windows, look at the volume control icon on the taskbar.
- If headphones, earphones or external speakers are connected to the line-out port on the computer's right panel, the internal speakers automatically turn off.

I want to eject the CD or DVD tray without turning on the power. I cannot eject the CD or DVD tray.

There is a mechanical eject button on the CD-ROM or DVD-ROM drive. Simply insert the tip of a pen or paperclip and push to eject the tray.



The floppy drive cannot access a diskette.

Check the following:

- Make sure the diskette is properly inserted in the floppy drive.
- Make sure the diskette is formatted.
- If the diskette is not the cause of the problem, the floppy drive may be dirty. Clean it using a drive cleaning kit. Follow the instructions included with the kit.

The CD or DVD drive cannot access a disc.

Check the following:

- Make sure the disc is supported by the drive. If your computer has a CD-ROM drive, it can read CDs but cannot read DVDs. If your computer has a DVD drive, it can read DVDs in addition to CDs.
- When placing the CD or DVD in the drive tray, make sure it is secure in the spindle on the drive tray.
- Make sure the CD or DVD is free from scratches or smudges. If the CD or DVD is dirty, clean it using a disc cleaning kit. Remember to follow the instructions included with the kit.
- If the problem does not lie with the disc, your CD or DVD drive may be dirty. Clean it using a drive cleaning kit. Follow the instructions included with the kit.

The keyboard does not respond.

Try attaching an external keyboard to the USB connector on the computer's rear. If it works, contact your dealer or an authorized service center as the internal keyboard cable may be loose.

The serial mouse does not work.

Check the following:

- Make sure that the serial cable is plugged securely into the serial port.
- During the POST, press **F2** to access the BIOS Utility and verify that the serial port is enabled. See "BIOS Utility" on page 45 for more details.

The printer does not work.

Check the following:

- Make sure that the printer is connected to a power outlet and that it is turned on.
- Depending on your connection (USB or parallel), make sure that the printer cable is connected securely to the appropriate port on your computer and the corresponding port on the printer.
- During POST, press **F2** to access the BIOS Utility and verify that the parallel port is enabled if you use a parallel printer.

I want to set up my location to use the internal modem.

To properly use your communications software, you need to set up your location:

1. Click on **Start**, **Control Panel**.
2. Double-click on **Phone and Modem Options**.
3. Click on the **Dialing Rules** tab and begin setting up your location.

Refer to Windows Help and Support.

Requesting service

International Traveler's Warranty (ITW)

Your computer is backed by an International Traveler's Warranty (ITW) that gives you security and peace of mind when traveling. Our worldwide network of service centers are there to give you a helping hand.

An ITW passport comes with your computer. This passport contains all you need to know about the ITW program. A list of available, authorized service centers is in this handy booklet. Read this passport thoroughly.

Always have your ITW passport on hand, especially when you travel to receive the benefits from our support centers. Place your proof-of-purchase in the flap located inside the front cover of the ITW passport.

If the country you are traveling in does not have an Acer-authorized ITW service site, you can still get in contact with our offices worldwide.

Please consult www.acersupport.com.

Before you call

Please have the following information available when you call Acer for online service, and please be at your computer when you call. With your support, we can reduce the amount of time a call takes and help solve your problems efficiently.

If there are error messages or beeps reported by your computer, write them down as they appear on the screen (or the number and sequence in the case of beeps).

You are required to provide the following information:

Name:____

Address:______________________________________

____

Telephone number:_____________________________

Machine and model type:________________________

Serial number:__________________________________

Date of purchase:______________________________

Appendix A

Specifications

This appendix lists the general specifications of your computer.

Microprocessor

- Mobile Intel® Pentium® 4 processor with 512 KB L2 cache

  - or -

  Intel® Celeron® processor with 128 KB L2 cache

Memory

- Main memory expandable to 2 GB
- Two DDR DIMM slots
- Support DDR 266/333 256MB, 512MB, 1GB SDRAM modules
- 512 KB Flash ROM BIOS; Shadow RAM support

Data storage

- One 3.5-inch internal floppy drive
- One high-capacity, Enhanced-IDE hard disk
- One 5.25-inch internal CD-ROM, DVD-ROM, DVD/CD-RW combo, or DVD rewritable

Display and video

- 14.1" or 15” Thin-Film Transistor (TFT) liquid crystal-display (LCD) displaying 32-bit true-color at 1024x768 eXtended Graphics Array (XGA) resolution
- 3D capabilities
- Simultaneous LCD and CRT display support
- Dual display capability

Audio

- 16-bit AC’97 stereo audio with built-in wavetable synthesizer
- Dual speakers
- Windows Sound System-compatible
- Separate audio ports for line-out, line-in devices

Keyboard and pointing device

- 84/85-key Windows keyboard
- Ergonomically-centered touchpad pointing device with scroll function

I/O ports

- Two type II PC Card slots
- One RJ-11 phone jack (V.90/V.92, 56Kbps modem)
- One RJ-45 network jack (Ethernet 10/100BaseT)
- One DC-in jack (AC adapter)
- One parallel port (ECP/EPP compliant)
- One external monitor port
- One Line-out jack (3.5mm minijack)
- One Line-in jack (3.5mm minijack)
- Four USB 2.0 ports

Weight and dimensions

- 3.36 kg (7.4 lbs) for 15.0" TFT model with battery
- 3.27 kg (7.2 lbs) for 14.1" TFT model with battery
- 332 (W) x 294 (D) x 39.4~39.9 (H) mm

Environment

- Temperature
  - Operating: 5°C ~ 35°C
  - Non-operating: -10°C ~ 60°C
- Humidity (non-condensing)
  - Operating: 20% ~ 85% RH
  - Non-operating: 20% ~ 85% RH

System

- Microsoft Windows XP Home/Pro
- ACPI support
- DMI 2.0-compliant

Power

- Battery pack
  - 4000mAh Li-Ion battery pack

- AC adapter
  - 120-Watt
  - Auto sensing 100~240Vac, 50~60Hz

Options

- 256MB/512MB/1GB memory upgrade module
- Additional AC adapter and battery pack

Appendix B

Notices

This appendix lists the general notices of your computer.

FCC notice

This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the device and receiver
- Connect the device into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/television technician for help

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with FCC regulations.

Notice: Peripheral devices

Only peripherals (input/output devices, terminals, printers, etc.) certified to comply with the Class B limits may be attached to this equipment. Operation with non-certified peripherals is likely to result in interference to radio and TV reception.

Caution

Changes or modifications not expressly approved by the manufacturer could void the user’s authority, which is granted by the Federal Communications Commission, to operate this computer.

Use conditions

This part complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Notice: Canadian users

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Remarque à l’intention des utilisateurs canadiens

Cet appareil numérique de la classe B respected toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Modem notices

FCC

This equipment complies with Part 68 of the FCC rules. Located on the bottom side of the modem is a label that contains, among other information, the FCC Registration Number and Ringer Equivalence Number (REN) for this equipment. Upon request, you must provide this information to your telephone company.

If your telephone equipment causes harm to the telephone network, the telephone company may discontinue your service temporarily. If possible, they will notify you in advance. But, if advance notice is not practical, you will be notified as soon as possible. You will also be informed of your right to file a complaint with the FCC.

Your telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the proper functioning of your equipment. If they do, you will be notified in advance to give you an opportunity to maintain uninterrupted telephone service.

If this equipment should fail to operate properly, disconnect the equipment from the phone line to determine if it is causing the problem. If the problem is with the equipment, discontinue use and contact your dealer or vendor.

TBR 21

This equipment has been approved [Council Decision 98/482/EC - “TBR 21”] for pan-European single terminal connection to the Public Switched Telephone Network (PSTN). However, due to differences between the individual PSTNs provided in different countries, the approval does not, of itself, give an unconditional assurance of successful operation on every PSTN termination point. In the event of problems, you should contact your equipment supplier in the first instance.

Important safety instructions

Read these instructions carefully. Save these instructions for future reference.

1 Follow all warnings and instructions marked on the product.

2 Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

3 Do not use this product near water.

4 Do not place this product on an unstable cart, stand, or table. The product may fall, causing serious damage to the product.

5 Slots and openings in the cabinet and the back or bottom are provided for ventilation; to ensure reliable operation of the product and to protect it from overheating, these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should never be placed near or over a radiator or heat register, or in a built-in installation unless proper ventilation is provided.

6 This product should be operated from the type of power indicated on the marking label. If you are not sure of the type of power available, consult your dealer or local power company.

7 Do not allow anything to rest on the power cord. Do not locate this product where persons will walk on the cord.

8 If an extension cord is used with this product, make sure that the total ampere rating of the equipment plugged into the extension cord does not exceed the extension cord ampere rating. Also, make sure that the total rating of all products plugged into the wall outlet does not exceed the fuse rating.

9 Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

10 Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage points or other risks. Refer all servicing to qualified service personnel.

11 Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- **a** When the power cord or plug is damaged or frayed
- **b** If liquid has been spilled into the product
- **c** If the product has been exposed to rain or water
- **d** If the product does not operate normally when the operating instructions are followed. Adjust only those controls that are covered by the operating instructions since improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal condition.
- **e** If the product has been dropped or the cabinet has been damaged
- **f** If the product exhibits a distinct change in performance, indicating a need for service.

12 Replace the battery with the same type as the product's battery we recommend. Use of another battery may present a risk of fire or explosion. Refer battery replacement to a qualified serviceman.

13 Warning! Batteries may explode if not handled properly. Do not disassemble or dispose of them in fire. Keep them away from children and dispose of used batteries promptly.

14 Use only the proper type of power supply cord set (provided in your accessories box) for this unit. It should be a detachable type: UL listed/CSA certified, type SPT-2, rated 7A 125V minimum, VDE approved or its equivalent. Maximum length is 15 feet (4.6 meters).

Laser compliance statement

The CD or DVD drive used with this computer is a laser product. The CD or DVD drive's classification label (shown below) is located on the drive.

CLASS 1 LASER PRODUCT
CAUTION: VISIBLE AND INVISIBLE LASER RADIATION WHEN OPEN. AVOID EXPOSURE TO BEAM.

APPAREIL A LASER DE CLASSE 1 PRODUIT
LASERATTENTION: RADIATION DU FAISCEAU LASER INVISIBLE EN CAS D'OUVERTURE. EVITTER TOUTE EXPOSITION AUX RAYONS.

LUOKAN 1 LASERLAITE LASER KLASSE 1
VORSICHT: UNSICHTBARE LASERSTRAHLUNG, WENN ABDECKUNG GEÖFFNET NICHT DEM STRAHLL AUSSETZEN

PRODUCTO LÁSER DE LA CLASE I
ADVERTENCIA: RADIACIÓN LÁSER INVISIBLE AL SER ABIERTO. EVITE EXPONERSE A LOS RAYOS.

ADVARSEL: LASERSTRÅLING VEDÅBNING SE IKKE IND I STRÅLEN.

VARO! LAVATTAESSA OLET ALTTINA LASERSÅTEILYLLE.
VARNING: LASERSTRÅLNING NÅR DENNA DEL ÅR ÖPPNAD ÅLÅ TUIJOTA SÅTEESEENSTIRRA EJ IN I STRÅLEN

VARNING: LASERSTRÅLNING NAR DENNA DEL ÅR ÖPPNADSTIRRA EJ IN I STRÅLEN

ADVARSEL: LASERSTRÅLING NAR DEKSEL ÅPNESSTIRR IKKE INN I STRÅLEN

Lithium battery statement

The TravelMate 240/250 series uses the lithium battery, models BTP-58A1, BTP-59A1 and BTP-60A1 only.

CAUTION
Danger of explosion if battery is incorrectly replaced. Replace only with the

same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

ADVARSEL!
Lithiumbatteri - Eksplosionsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type. Léver det brugte batteri tilbage til leverandøren.

ADVARSEL
Eksplosjonsfare ved feilaktig skifte av batteri. Benytt samme batteritype eller en tilsvarende type anbefalt av apparatfabrikanten. Brukte batterier kasseres i henhold til fabrikantens instruksjoner.

VARNING
Explosionsfara vid felaktigt batteribyte. Anvãnd samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera anvãnt batteri enligt fabrikantens instruktion.

VAROITUS
Päristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan laitevalmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.

VORSICHT!
Explosionsgefahr bei unsachgemäßen Austausch der Batterie Ersatz nur durch denselben oder einem vom Hersteller empfohlenem ähnlichen Typ. Entsorgung gebrauchter Batterien nach Angaben des Herstellers.

Year 2000 compliance statement

The TravelMate 240/250 series notebook computer carries the "Hardware NSTL Tested Year 2000 Compliant" logo, which certifies that this model has been tested by NSTL using the YMark2000 test, and has been found to meet NSTL's standards for Year 2000 hardware compliance.

HARDWARE
NSTL
TESTED™
Year 2000
Compliant

LCD pixel statement

The LCD unit is produced with high-precision manufacturing techniques. Nevertheless, some pixels may occasionally misfire or appear as black or colored dots. This has no effect on the recorded image and does not constitute a malfunction.

A-Tick notice

Apparatus Claims of U.S. Patent Nos. 4,631,603, 4,577,216, 4,819,098, and 4,907,093 licensed for limited viewing uses only.

For safety reasons, only connect headsets with a telecommunications compliance label. This includes customer equipment previously labelled permitted or certified.

The unit shall be connected to Telecommunication Network through a line cord which meets the requirements of ACA Technical Standard TS008.

Australian approved mains cord set shall be used with the equipment.

Regulatory information for 802.11b WLAN

Note: Below regulatory information is for models with 802.11b wireless LAN only.

Regulatory Information

The Wireless module must be installed and used in strict accordance with the manufacturer's instructions. This device complies with the following radio frequency and safety standards.

Canada - Industry Canada (IC)

This device complies with RSS 210 of Industry Canada.

Europe - EU Declaration of Conformity

This device complies with the standards listed below, following the provisions of the EMC Directive 89/336/EEC:

- ETSI EN 301 489-1/17
- ETSI EN 300 328-2

USA - Federal Communications Commission (FCC)

This device complies with Part 15 of FCC Rules. Operation of the devices in an Wireless LAN System is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference that may cause undesired operation.

Exposure to Radio Frequency Radiation

The radiated output power of the Wireless module is far below the FCC radio frequency exposure limits. Nevertheless, the Wireless module shall be used in such a manner that the potential for human contact during normal operation is minimized.

The transmitter and the antenna are permanently installed inside the notebook, and are specific for this model (not for generic computer). The antenna of this device is installed on the top of the LCD display. For compliance with FCC radiation exposure limits. it should be operated with a separation distance of 20cm or more between the antenna and the body of the user, and the antenna should not be operated next to a nearby person.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment (example - use only shielded interface cables when connecting to computer or peripheral devices).

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Index

A
AC adapter
    caring for **v**
audio **25**
    troubleshooting **60**

B
battery pack
    caring for **v**
    charging indicator **11**
BIOS Utility **45**– **56**
    Advanced menu
        i/o device configuration **52**
        pci irq routing **53**
        primary master **50**
        secondary master **51**
    advanced menu **49**
    boot menu **55**
    exit menu **56**
    main menu **47**
    navigating **45**
    security menu **54**
BIOS utility **45**
brightness
    hotkeys **17**

C
caps lock **13**
    on indicator **11**
care
    AC adapter **v**
    battery pack **v**
    computer **iv**
CD
    troubleshooting **61**
CD-ROM
    ejecting **22**
    ejecting manually **60**
    troubleshooting **60**
cleaning
    computer **v**
computer
    bringing to meetings **28**
    caring for **iv**
    cleaning **v**
    disconnecting **27**
    features **3**, **9**
    indicators **11**
    keyboards **13**
    moving around **27**
    on indicator **11**
    performance **9**
    security **32**
    setting up a home office **29**
    taking home **28**
    traveling internationally **30**
    traveling on local trips **30**
    troubleshooting **58**
    turning off **iv**
CPU **46**

D
date
    setting in BIOS Utility **48**
display
    hotkeys **17**
    troubleshooting **59**, **60**
DVD **23**
    troubleshooting **61**
DVD movies
    playing **23**
DVD RW drive **9**

E
Ethernet **38**
Euro **17**, **18**

F
FAQ. See frequently-asked questions
floppy drive
    troubleshooting **61**
frequently-asked questions **59**
front view **3**

H
hard disk **22**
help
    online services **63**
Hibernation mode
    hotkey **16**
hotkeys **16**

I
indicator lights **11**

ITW. See warranty

K

keyboard **13**
  embedded numeric keypad **14**
  hotkeys **16**
  lock keys **13**
  troubleshooting **61**
  Windows keys **15**

L

LEDs **11**

M

media access
  on indicator **11**
memory
  installing **41– 42**
  upgrading **40**
modem **37**
mouse
  troubleshooting **61**

N

network **38**
Notebook Manager **43**
  hotkey **16**
notice
  year 2000 compliance **77**
num lock **13**
  on indicator **12**
numeric keypad
  embedded **14**
  num lock **14**

O

online services **63**
optical drive **22**
options
  memory upgrade **40**

P

parallel port
  setting in BIOS Utility **52**
PC Card **39**
  ejecting **39**
  inserting **39**
ports **37**
POST (power-on self-test) **45**
printer
  troubleshooting **62**
problems **59**
  CD **61**
  CD-ROM **60**
  diskette **61**
  display **59, 60**
  DVD **61**
  floppy drive **61**
  keyboard **61**
  printer **62**
  serial mouse **61**
  startup **59**
  troubleshooting **58**

Q

questions
  setting location for modem use **62**

S

safety
  CD-ROM **76**
  FCC notice **73**
  general instructions **74**
  modem notices **74**
scroll lock **13**
security
  keylock **32**
service
  when to call **v**
speakers
  hotkey **17**
  troubleshooting **60**
specifications **66**
Standby mode
  hotkey **16**
  status indicator **11**
status indicators **11**
storage **22**
  CD, DVD, or DVD/CD-RW combo drive **22**
  hard disk **22**
support
  information **63**

T

time
  setting in BIOS Utility **48**
touchpad **20**

  - hotkey **17**
  - using **20– 21**

travel
  - international flights **30**
  - local trips **30**

troubleshooting **58**

U

universal serial bus **38**

utility
  - BIOS Setup **45– 56**

V

view
  - front **5**
  - left **5**
  - rear **7**
  - right **6**

W

warranty
  - International Traveler's Warranty **63**

Windows keys **15**